

# Assembly instructions for ladder 5056

- ✎ Assembly and dismantling must be carried out by at least two people.
- ✎ Check that the two base pieces have their wheels attached, are in good condition and that they are complete with screw adjusting knobs in perfect working order.
- ✎ Hook a base onto the underside of one of the legs, ensuring that the leg is centrally positioned on the base, firmly tighten the clamps by hand. Do not use tools. Lock the wheels with the brakes.
- ✎ Open the legs of the ladder: keep the second leg raised off the ground and attach the second base.
- ✎ After attaching both bases, attach the three-base connecting cross bars which ensure rigidity and stability to the base.
- ✎ It is forbidden to climb on the ladder without the three cross bars in place.

Before climbing up the ladder ensure that:

- ✎ All the brakes are locked;
- ✎ The ladder is completely level by using the screw adjusting knobs, checking carefully with a plumb line or a spirit level;
- ✎ The platform is raised up to the desired height by applying the right tension to the rope: it is forbidden to raise or lower the platform whilst an operator is on the ladder.

- ✎ In order to take down the third cantilevered section of the ladder, pull on the rope until the locking latches are released and then accompany the descent of this section of the ladder.

The operator must remain inside the platform, using the safety protection bar and a safety harness fastened to the ladder.

No one must stand under the ladder: it is highly recommended to fence off the work area around the ladder to avoid the risk caused by falling objects and collisions which could destabilize the ladder.

Ladder load must not exceed: 100 kg.

